



Properly position and secure the form with a Steel Stake in each stake pocket.



Hook the Division Plates over the front and back forms.

The Street Smart Curb and Gutter Forming System is easy to set up when these simple installation procedures are followed:

1. Set the curb side of the Street Smart curb and gutter forming system first.
2. Use Steel Stakes and a string line to mark the grade to the proper elevation.
3. Position the first Street Smart form parallel with the string and put a Steel Stake in each of the stake pockets (Minimum of 2 Steel Stakes for each 10' length).
4. Check the form position and drive in the Steel Stakes. Raise the form to grade and use the stake pocket wedges to secure the form.
5. Connect the second Street Smart form to the first and put a Steel Stake in each of the stake pockets.
6. Position the second form and drive in the Steel Stakes. Raise the form to grade and use the stake pocket wedges to secure the form.
7. Repeat this procedure to set the entire curb side of the Street Smart.
8. Hook the Division (or Skeleton) Plates over the top of the curb side forms that are in position (minimum of 2 Division Plates for first 10' length and 1 for each subsequent 10' length). The Division Plates can now be used as a guide for positioning the gutter side of the Street Smart forming system.
9. Position the gutter side form opposite of the previously positioned curb side form.
10. Hook the Division Plates over the top of the gutter side form and put a Steel Stake in each of the stake pockets (minimum of 2 Steel Stakes for each 10' length).
11. Check the form position and drive in the Steel Stakes. Raise the form to grade and use the stake pocket wedges to secure the form.
12. Repeat this procedure to set the entire gutter side of the Street Smart.

13. Set the Curb Face Form on the Division Plates and secure the form with the Top Spreader (minimum of 1 Top Spreader for each 10' length).
14. Repeat this procedure to set the entire curb face of the Street Smart forming system.
15. Spray the form faces with Magic Kote® Form Release before concrete placement.

Equipment needs are slightly different for Flexible Form configurations. Contact a Symons representative for details.



Place the Top Spreader over the forms to secure the Curb Face Form.

CORPORATE HEADQUARTERS

1125 Byers Road
Miamisburg, OH 45342
937-866-0711

ACCESSORIES AND CHEMICALS

Customer Service: 888-977-9600
Technical Assistance: 877-266-7732
info@daytonsuperior.com

FORMING PRODUCTS

Customer Service: 800-800-7966
Technical Assistance: 877-266-7732
info@daytonsuperior.com